

# Cleaning Guide

FURNITURE CLEANING & DISINFECTING PROTOCOLS



**Table of Contents**

Knowing the Difference: Cleaning, Disinfectant, & Sanitizing..... 3

Antimicrobials..... 4

3D Laminates..... 5

Edgebanding..... 9

Glass..... 11

High Pressure Laminate (HPL).....12

    Woodgrains.....12

    Solid.....16

    Pattern.....20

Markerboards & Writable Glass..... 24

Paint.....25

Panel.....28

Resin.....28

Seating.....34

    Mesh..... 35

    Non-Woven..... 38

    Plastic..... 42

    Woven..... 44

Solid Surface.....45

Thermally Fused Laminate (TFL).....55

Wood.....59

Wool Felt..... 61

## Knowing the Difference: Cleaning, Disinfectant, & Sanitizing

Now, more than ever, cleanability is in the forefront of everyone's mind. That's why we've gathered information from our Alliance partners to provide you with accurate cleaning and disinfecting information. We're here to help answer questions about cleaning our products so you can provide a safe workspace.

- **Cleaning:** Cleaning is the process of removing visible debris, dirt, and dust and organizing a space. Cleaning may or may not kill bacteria and germs, but it will dilute their numbers and aid in lowering the risk of spreading infectious microbes.
  - **When to Clean:** Cleaning should be a routine process that occurs on a daily, weekly, monthly, and seasonal basis. Basic housekeeping maintains order, reduces the growth of potentially harmful organisms, helps keep pests under control, and protects the investment you've made in your home and belongings.
- **Sanitizing:** When a product claims to sanitize a surface, it is promising to make the surface free of germs that could be harmful to your health according to public health standards or requirements. Sanitizing reduces, not kills, the number and growth of bacteria, viruses, and fungi.
  - **When to Sanitize:** Sanitization is important for health and hygiene and is particularly important on communal surfaces like counter-tops, doorknobs, light switches, touch-pads, and any surface that comes in contact with body fluids.
- **Disinfectant:** The act of disinfecting kills microscopic organisms (germs, viruses, fungi) on surfaces. Disinfecting does not necessarily remove visible dirt and debris from a surface and is much more effective if basic cleaning is done first.
  - **When to Disinfect:** When someone in the workplace is ill or if someone has a compromised immune system. Following label instructions and using disinfectants correctly is vital to killing microorganisms.

[Link to information](#)

## Antimicrobial

With the current concerns about cleaning and disinfecting, antimicrobials are gaining attention. While antimicrobials were very popular in healing environments for a number of years, research has found they can do more harm than good. Healthcare institutions are learning about this reversal in opinion from a variety of sources, including the Healthier Hospitals Initiative (HHI). Recent studies have shown that bacteria can become immune to the antimicrobial property. Therefore, the bacteria is morphing into a 'super bug'.

According to the FDA, Antimicrobial Resistance is recognized as a growing global threat. In 2014, The White House announced the National Strategy for Combating Antibiotic Resistance Bacteria (CARB), underscoring the need to address antimicrobial resistance. This movement began with a focus around antibiotics and consumables, but has spread to include products for healing environments. The FDA plays an integral role in these efforts.

It's important to understand what antimicrobials in surfaces do. For example, you may find them in kitchen countertops. They claim to protect the surface from the growth of mold and mildew that cause stains and odors. The antimicrobials in those surfaces do not kill microbes. It is there to keep the surface looking and smelling better longer. Another common place to find antimicrobials is textiles. Again, they are protecting the surface from the growth of mold and mildew that cause stains and odors.

With this in mind, most of our surfaces do not contain antimicrobials. We do offer a limited number of materials with antimicrobials for those who do want them. You'll find them mainly in seating upholsteries, however, if you are needing antimicrobials in other materials, you can do so through our COM and CSL programs.

General reading about cleaning/disinfecting/antimicrobials:

[Consumer Reports](#)

[OSHA](#)

[CDC, Disinfecting Building Facilities](#)

[Common Line, Pros and Cons of Antimicrobial Surfaces](#)

[Common Line, Improving Disinfection Outcomes with Electrostatic Technologies](#)

[Common Line, How to Stop Custodian Induced Contamination](#)

[Healthier Hospitals, Safer Chemicals](#)

## 3D Laminates

Clean 3D laminate surfaces with a mild soap and water solution. Wipe dry with a soft, clean cloth.

It is recommended to thoroughly rinse with clean water and wipe completely dry after exposure to cleaners/disinfectants.

\*The clear overlay/top-coat used on the 3D Laminate naturally inhibits the growth of bacteria. An antimicrobial chemical is not added to this material.

	3D LAMINATE
ANTIMICROBIAL	Yes*
CLEANING	Mild Soap & Water
AGAR™ POWERQUAT	Yes
BIORTROL™ BIREX SE®	Yes
BLEACH/WATER SOLUTION 1:5	Yes
CALTECH® CITRACE®	Yes
CALTECH® PRECISE® HOSPITAL FOAM CLEANER DISINFECTANT	Yes
CALTECH® PRECISE® QTB SPRAY	Yes
CLOROX® BROAD SPECTRUM QUATERNARY DISINFECTANT CLEANER	Yes
CLOROX HEALTHCARE® DISPATCH® HOSPITAL CLEANER DISINFECTANT WITH BLEACH	Yes
CLOROX HEALTHCARE® BLEACH GERMICIDAL CLEANER	Yes

## 3D Laminates (Continued)

	3D LAMINATE
CLOROX HEALTHCARE® BLEACH GERMICIDAL WIPES	Yes
CLOROX HEALTHCARE® EZ-KILL WIPES	Yes
"CLOROX HEALTHCARE® VERSASURE™ ALCOHOL-FREE DISINFECTANT CLEANER WIPES"	Yes
CURRENT TECHNOLOGIES BLEACH-RITE® DISINFECTING SPRAY	Yes
DIVERSEY™ ACCEL® INTERVENTION WIPES	Yes
DIVERSEY™ OXIVIR® 1 RTU	Yes
DIVERSEY™ OXIVIR® TB	Yes
DIVERSEY™ VIREX® II 256	Yes
DIVERSEY™ VIROX™ AHP® 5	Yes
ECOLAB® ASEPTICARE™	Yes
ECOLAB® ASEPTICARE™ TB II	Yes
ECOLAB® OXYCIDETM DAILY DISINFECTANT CLEANER	Yes
DIVERSEY™ VIROX™ AHP® 5	Yes
ERC PERFORMANCE WIPES	Yes
FANTASTIK® ALL PURPOSE CLEANER	Yes

## 3D Laminates (Continued)

	3D LAMINATE
FORMULA 409® ANTIBACTERIAL ALL-PURPOSE CLEANER	Yes
LYSOL® DISINFECTANT SPRAY	Yes
LYSOL ONE STEP FLOOR CLEANER	Yes
MCKESSON DISPOSABLE GERMICIDAL SURFACE WIPES	Yes
MCKESSON PRO-TECH RTU DISINFECTANT CLEANER	Yes
METREX™ CAVICIDE™	Yes
METREX™ CAVICIDE™ AF	Yes
NCL® AVISTAT-D™ READY TO USE SPRAY DISINFECTANT CLEANER	Yes
NCL® MICRO-CHEM PLUS™	Yes
PDI® SANI-CLOTH® AF3 GERMICIDAL DISPOSABLE WIPES	Yes
PDI® SANI-CLOTH® HB GERMICIDAL	Yes
PDI® SANI-CLOTH® PLUS GERMICIDAL DISPOSABLE WIPE	Yes
PDI® SUPER SANI-CLOTH® GERMICIDAL DISPOSABLE WIPE	Yes
RUSS MEDICAL FADE-A-DYNE II	Yes
SAFETEC® SANIZIDE PLUS®	Yes

### 3D Laminates (Continued)

	3D LAMINATE
SANI-KLEEN BROAD-CIDE 128	Yes
SCICAN OPTIM® 1 WIPES	Yes
SCICAN OPTIM® 33TB	Yes
TEXAS GULF INDUSTRIES SANTIMINE 150	Yes
VIROX® PREEMPT™ RTU	Yes
WEXFORD WEX-CIDE 128	Yes



## Edgebanding

	EDGEBANDING
ANTIMICROBIAL	No
CLEANING	Mild Soap & Water
BLEACH/WATER SOLUTION 1:10 (10%)	Yes
CLEAR AMMONIA ALL-PURPOSE CLEANER	Yes
CLOROX HEALTHCARE® DISPATCH® HOSPITAL CLEANER DISINFECTANT WITH BLEACH	Yes
DIVERSEY™ VIREX® II 256	Yes
ECOLAB® A-456® II	Yes
ECOLAB® ENDURE 320 HAND SANITIZER	Yes
ECOLAB® OXYCIDE™ DAILY DISINFECTANT CLEANER	Yes
ETHANOL 95%	Yes
EVACLEAN™ PURTABS	Yes
GCLEAN(R) G200 SURFACE SANITIZER	Yes
HILLYARD FOAMING HAND SANITIZER	Yes
HYDROGEN PEROXIDE (3% SOLUTION. THIS IS NOT HYDROGEN PEROXIDE VAPOR/MIST)"	Yes
ISOPROPYL/RUBBING ALCOHOL (70%)	Yes

## Edgebanding (Continued)

	EDGEBANDING
JAY-KEM PH NEUTRAL COMMERCIAL FLOOR CLEANER	Yes
LYSOL® DISINFECTANT SPRAY	Yes
LYSOL® DISINFECTANT MAX COVER MIST	Yes
LYSOL® DISINFECTING WIPES	Yes
RECKIT BENCKIER/LYSOL ONE STEP FLOOR CLEANER	Yes
PINE SOL ALL PURPOSE CLEANER	Yes
SIMPLE GREEN®	Yes
SSS® SANOTRACIN	Yes
WEXFORD WEX-CIDE 128	Yes

## Glass

Clean as normal with a soft cloth and mild, non-alkaline detergent using moderate pressure.

Detergent must be free of silicone and other polishing additives that may leave a residue causing streaks to form. Abrasive and caustic cleaners are not to be used.

Excessive pressure or hard scrubbing motions may damage the painted frost glass surface.

Wipe glass surface until dry; liquids left on the glass may cause staining.

	GLASS	BACK PAINTED GLASS
ANTIMICROBIAL	No	No
CLEANING	Mild Soap & Water	Mild Soap & Water
GLASS PLUS®	Yes	Yes*
ISOPROPYL/RUBBING ALCOHOL (70%)	Yes	Yes*
RECKIT BENCKIER/LYSOL® WIPES	Yes	Yes*
WINDEX®	Yes	Yes*

## High Pressure Laminates (HPL): Woodgrains

Wipe the surface, moving with the grain on laminate surfaces. Avoid exposing furniture to extreme heat or cold; also avoid wide humidity variance.

It is recommended to thoroughly rinse with clean water and wipe completely dry after exposure to cleaners/disinfectants

\* Causes slight change of gloss or color.

	WOODGRAIN																	
	<u>Almond</u>	<u>Amber</u>	<u>Brazilwood</u>	<u>Brighton</u>	<u>Canyon</u>	<u>Clear Zebrawood</u>	<u>Cordoba</u>	<u>Driftwood</u>	<u>Huntington</u>	<u>Midtown</u>	<u>Mocha</u>	<u>Monterey</u>	<u>Portobello</u>	<u>Sable</u>	<u>Sedona</u>	<u>Tribeca</u>	<u>Tuscan</u>	<u>Urban</u>
ANTIMICROBIAL	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No
CLEANING	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water
BLEACH/WATER SOLUTION 1:10 (10%)	Yes												Yes	Yes				
CLOROX HEALTHCARE® DISPATCH® HOSPITAL CLEANER DISINFECTANT WITH BLEACH	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*
CLOROX HEALTHCARE® BLEACH GERMICIDAL CLEANER	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*
CLOROX HEALTHCARE® VERSASURE™ ALCOHOL-FREE DISINFECTANT CLEANER WIPES	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
CLOROX® DISINFECTING WIPES	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
CLOROX HEALTHCARE® BLEACH GERMICIDAL WIPES	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes

## High Pressure Laminates (HPL): Woodgrains (Continued)

	WOODGRAIN																	
	<u>Almond</u>	<u>Amber</u>	<u>Brazilwood</u>	<u>Brighton</u>	<u>Canyon</u>	<u>Clear Zebra</u> <u>wood</u>	<u>Cordoba</u>	<u>Driftwood</u>	<u>Huntington</u>	<u>Midtown</u>	<u>Mocha</u>	<u>Monterey</u>	<u>Portobello</u>	<u>Sable</u>	<u>Sedona</u>	<u>Tribeca</u>	<u>Tuscan</u>	<u>Urban</u>
CLOROX HEALTHCARE® HYDROGEN PEROXIDE CLEANER DISINFECTANT WIPES	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
ULTRA CLOROX® REGULAR BLEACH 8.25%	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
DIVERSEY™ EXPOSE® II 256	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes			
DIVERSEY™ OXIVIR® 1	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes			
DIVERSEY™ OXIVIR® TB	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes			
DIVERSEY™ STRIDE® FLORAL NEUTRAL CLEANER	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*			
DIVERSEY™ VIREX® II 256	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes			
ECOLAB® A-456® II	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes			
ECOLAB® ENDURE HAND SANITIZER	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*			
EVACLEAN™ PURTABS	Yes												Yes	Yes				
FANTASTIK® ALL PURPOSE CLEANER	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes			
FORMULA 409® ANTIBACTERIAL ALL-PURPOSE CLEANER	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes			
GCLEAN(R) G200 SURFACE SANITIZER	Yes												Yes	Yes				

## High Pressure Laminates (HPL): Woodgrains (Continued)

	WOODGRAIN																	
	<u>Almond</u>	<u>Amber</u>	<u>Brazilwood</u>	<u>Brighton</u>	<u>Canyon</u>	<u>Clear Zebra</u> <u>wood</u>	<u>Cordoba</u>	<u>Driftwood</u>	<u>Huntington</u>	<u>Midtown</u>	<u>Mocha</u>	<u>Monterey</u>	<u>Portobello</u>	<u>Sable</u>	<u>Sedona</u>	<u>Tribeca</u>	<u>Tuscan</u>	<u>Urban</u>
HYDROGEN PEROXIDE (3% SOLUTION. THIS IS NOT HYDROGEN PEROXIDE VAPOR/ MIST)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
ISOPROPYL ALCOHOL (50% & 70%)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
JAY-KEM PH NEUTRAL COMMERCIAL FLOOR CLEANER	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
LYSOL ONE STEP FLOOR CLEANER	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
LYSOL ONE STEP FLOOR CLEANER	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
METREX™ CAVIWIPES	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
METREX™ CAVIWIPES™ BLEACH	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*
MR. CLEAN®	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
PDI® SANI-PRIME® GERMICIDAL SPRAY	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
PDI® SUPER SANI-CLOTH® GERMICIDAL DISPOSABLE WIPE	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
PINE SOL ALL PURPOSE CLEANER	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
PURELL ADVANCED INSTANT HAND SANITIZER	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*
PURELL® PROFESSIONAL SURFACE DISINFECTANT WIPES	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*

## High Pressure Laminates (HPL): Woodgrains (Continued)

	WOODGRAIN																	
	<u>Almond</u>	<u>Amber</u>	<u>Brazilwood</u>	<u>Brighton</u>	<u>Canyon</u>	<u>Clear Zebra</u> <u>wood</u>	<u>Cordoba</u>	<u>Driftwood</u>	<u>Huntington</u>	<u>Midtown</u>	<u>Mocha</u>	<u>Monterey</u>	<u>Portobello</u>	<u>Sable</u>	<u>Sedona</u>	<u>Tribeca</u>	<u>Tuscan</u>	<u>Urban</u>
SIMPLE GREEN®	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
SSS® SANOTRACIN	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
STERIS LPH®	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
UNIMED ACCEL® TB	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
WEXFORD WEX-CIDE 128	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
WINDEX®	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes

## High Pressure Laminates (HPL): Solid

	SOLID											
	<u>Antique White</u>	Chamois	Cinder	Cloud	<u>Designer White</u>	<u>Fog</u>	<u>Frosty White</u>	Graphite	<u>Sandstone</u>	<u>Shadow</u>	<u>Storm</u>	<u>Wallaby</u>
ANTIMICROBIAL	No	No	No	No	No	No	No	No	No	No	No	No
CLEANING	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water
BLEACH/WATER SOLUTION 1:10 (10%)	Yes	Yes	Yes	Yes	Yes	Yes	Yes		Yes	Yes	Yes	Yes
CLOROX HEALTHCARE® DISPATCH® HOSPITAL CLEANER DISINFECTANT WITH BLEACH	Yes*	No	No	No	Yes*	Yes*	Yes*	No	Yes*	Yes*	Yes*	Yes*
CLOROX HEALTHCARE® BLEACH GERMICIDAL CLEANER	Yes*	No	No	No	Yes*	Yes*	Yes*	No	Yes*	Yes*	Yes*	Yes*
CLOROX HEALTHCARE® VERSASURE™ ALCOHOL-FREE DISINFECTANT CLEANER WIPES"	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
CLOROX® DISINFECTING WIPES	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
CLOROX HEALTHCARE® BLEACH GERMICIDAL WIPES	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
CLOROX HEALTHCARE® HYDROGEN PEROXIDE CLEANER DISINFECTANT WIPES	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
ULTRA CLOROX® REGULAR BLEACH 8.25%	Yes	No	No	No	Yes							
DIVERSEY™ EXPOSE® II 256	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
DIVERSEY™ OXIVIR® 1	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes



## High Pressure Laminates (HPL): Solid (Continued)

	SOLID											
	<u>Antique White</u>	Chamois	Cinder	Cloud	<u>Designer White</u>	<u>Fog</u>	<u>Frosty White</u>	Graphite	<u>Sandstone</u>	<u>Shadow</u>	<u>Storm</u>	<u>Wallaby</u>
DIVERSEY™ OXIVIR® TB	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
DIVERSEY™ STRIDE® FLORAL NEUTRAL CLEANER	Yes*				Yes*	Yes*	Yes*		Yes*	Yes*	Yes*	Yes*
DIVERSEY™ VIREX® II 256	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
ECOLAB® A-456® II	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
ECOLAB® ENDURE HAND SANITIZER	Yes*				Yes*	Yes*	Yes*		Yes*	Yes*	Yes*	Yes*
EVACLEAN™ PURTABS	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes				
FANTASTIK® ALL PURPOSE CLEANER	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
FORMULA 409® ANTIBACTERIAL ALL-PURPOSE CLEANER	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
GCLEAN(R) G200 SURFACE SANITIZER	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes				
GLASS PLUS®	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
HILLYARD FOAMING HAND SANITIZER	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
HYDROGEN PEROXIDE (3% SOLUTION. THIS IS NOT HYDROGEN PEROXIDE VAPOR/MIST)"	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
ISOPROPYL ALCOHOL (50% & 70%)	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes

## High Pressure Laminates (HPL): Solid (Continued)

	SOLID											
	<u>Antique White</u>	Chamois	Cinder	Cloud	<u>Designer White</u>	<u>Fog</u>	<u>Frosty White</u>	Graphite	<u>Sandstone</u>	<u>Shadow</u>	<u>Storm</u>	<u>Wallaby</u>
JAY-KEM PH NEUTRAL COMMERCIAL FLOOR CLEANER	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
LYSOL ONE STEP FLOOR CLEANER	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
LYSOL DISINFECTANT SPRAY	Yes	Yes			Yes	Yes	Yes		Yes	Yes	Yes	Yes
LYSOL® DISINFECTANT MAX COVER MIST	Yes	Yes			Yes	Yes	Yes		Yes	Yes	Yes	Yes
LYSOL® DISINFECTING WIPES	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
METREX™ CAVIWIPES	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
METREX™ CAVIWIPES™ BLEACH	Yes*				Yes*	Yes*	Yes*		Yes*	Yes*	Yes*	Yes*
MR. CLEAN®	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
PDI® SANI-PRIME® GERMICIDAL SPRAY	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
PDI® SUPER SANI-CLOTH® GERMICIDAL DISPOSABLE WIPE	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
PINE SOL ALL PURPOSE CLEANER	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
PURELL ADVANCED INSTANT HAND SANITIZER	Yes*				Yes*	Yes*	Yes*		Yes*	Yes*	Yes*	Yes*
PURELL® PROFESSIONAL SURFACE DISINFECTANT WIPES	Yes*				Yes*	Yes*	Yes*		Yes*	Yes*	Yes*	Yes*
SIMPLE GREEN®	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes

## High Pressure Laminates (HPL): Solid (Continued)

	SOLID											
	<u>Antique White</u>	Chamois	Cinder	Cloud	<u>Designer White</u>	<u>Fog</u>	<u>Frosty White</u>	Graphite	<u>Sandstone</u>	<u>Shadow</u>	<u>Storm</u>	<u>Wallaby</u>
SSS® SANOTRACIN	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
STERIS LPH®	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
UNIMED ACCEL® TB	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
WEXFORD WEX-CIDE 128	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes
WINDEX®	Yes				Yes	Yes	Yes		Yes	Yes	Yes	Yes

## High Pressure Laminates (HPL): Pattern

	PATTERN														
	<a href="#">Bronze Legacy</a>	Canyon Zephyr	<a href="#">Carbon Evolv</a>	Desert Zephyr	Grey Glace	Misted Zephyr	Morro Zephyr	Mushroom Tigris	Nickel Evolv	Silicon	Tawny Legacy	Titanium Evolv	Tungsten Evolv	White Nebula	<a href="#">White Tigris</a>
ANTIMICROBIAL	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No
CLEANING	Mild Soap & Water with Grain	Mild Soap & Water with Grain	Mild Soap & Water with Grain	Mild Soap & Water with Grain	Mild Soap & Water with Grain	Mild Soap & Water with Grain	Mild Soap & Water with Grain	Mild Soap & Water with Grain	Mild Soap & Water with Grain	Mild Soap & Water with Grain	Mild Soap & Water with Grain	Mild Soap & Water with Grain	Mild Soap & Water with Grain	Mild Soap & Water with Grain	Mild Soap & Water with Grain
BENEFACT®	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
CLOROX HEALTHCARE® DISPATCH® HOSPITAL CLEANER DISINFECTANT WITH BLEACH	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*
CLOROX HEALTHCARE® BLEACH GERMICIDAL CLEANER	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*
CLOROX HEALTHCARE® VERSASURE™ ALCOHOL-FREE DISINFECTANT CLEANER WIPES	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
CLOROX® DISINFECTING WIPES	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
CLOROX HEALTHCARE® BLEACH GERMICIDAL WIPES	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
CLOROX HEALTHCARE® HYDROGEN PEROXIDE CLEANER DISINFECTANT WIPES	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
ULTRA CLOROX® REGULAR BLEACH 8.25%															
DIVERSEY™ EXPOSE® II 256	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes

## High Pressure Laminates (HPL): Pattern (Continued)

	PATTERN														
	<u>Bronze Legacy</u>	Canyon Zephyr	<u>Carbon Evolv</u>	Desert Zephyr	Grey Glace	Misted Zephyr	Morro Zephyr	Mushroom Tigris	Nickel Evolv	Silicon	Tawny Legacy	Titanium Evolv	Tungsten Evolv	White Nebula	<u>White Tigris</u>
DIVERSEY™ OXIVIR® 1	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
DIVERSEY™ OXIVIR® TB	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
DIVERSEY™ STRIDE® FLORAL NEUTRAL CLEANER	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*
DIVERSEY™ VIREX® II 256	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
ECOLAB® A-456® II	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
ECOLAB® ENDURE HAND SANITIZER	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*
FANTASTIK® ALL PURPOSE CLEANER	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
FORMULA 409® ANTIBACTERIAL ALL-PURPOSE CLEANER	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
GLASS PLUS®	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
HILLYARD FOAMING HAND SANITIZER	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
HYDROGEN PEROXIDE (3% SOLUTION. THIS IS NOT HYDROGEN PEROXIDE VAPOR/MIST)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
ISOPROPYL ALCOHOL	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
JAY-KEM PH NEUTRAL COMMERCIAL FLOOR CLEANER	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes

## High Pressure Laminates (HPL): Pattern (Continued)

	PATTERN														
	<u>Bronze Legacy</u>	Canyon Zephyr	<u>Carbon Evolv</u>	Desert Zephyr	Grey Glace	Misted Zephyr	Morro Zephyr	Mushroom Tigris	Nickel Evolv	Silicon	Tawny Legacy	Titanium Evolv	Tungsten Evolv	White Nebula	<u>White Tigris</u>
LYSOL ONE STEP FLOOR CLEANER	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
LYSOL® DISINFECTANT SPRAY	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
LYSOL DISINFECTANT MAX COVER MIST	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
LYSOL® DISINFECTING WIPES	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
METREX™ CAVIWIPES	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
METREX™ CAVIWIPES™ BLEACH	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*
MR. CLEAN®	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
PDI® SANI-PRIME® GERMICIDAL SPRAY	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
PDI® SUPER SANI-CLOTH® GERMICIDAL DISPOSABLE WIPE	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
PINE SOL ALL PURPOSE CLEANER	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
PURELL ADVANCED INSTANT HAND SANITIZER	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*
PURELL® PROFESSIONAL SURFACE DISINFECTANT WIPES	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*	Yes*
SIMPLE GREEN®	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes

## High Pressure Laminates (HPL): Pattern (Continued)

	PATTERN														
	<u>Bronze Legacy</u>	Canyon Zephyr	<u>Carbon Evolv</u>	Desert Zephyr	Grey Glace	Misted Zephyr	Morro Zephyr	Mushroom Tigris	Nickel Evolv	Silicon	Tawny Legacy	Titanium Evolv	Tungsten Evolv	White Nebula	<u>White Tigris</u>
SSS® SANOTRACIN	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
STERIS LPH®	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
UNIMED ACCEL® TB	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
WEXFORD WEX-CIDE 128	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
WINDEX®	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes

## Markerboard & Writable Glass

Expo dry erase markers are recommended for markerboard and writable glass surfaces.

All other markers are not recommended, as they may leave undesirable results when erased.

Permanent or non-dry erase markers should not be used.

Dry erase erasers, not chalk board erasers, should be used to remove marker. Replace the erasers when heavily soiled.

Clean surface with Expo markerboard cleaner. Residue from other types of cleaners may cause markers to smear when erased.

	DRY ERASE MARKERBOARD
ANTIMICROBIAL	No
CLEANING	Mild Soap & Water with Grain



## Paint

Clean surfaces with a mild soap and water solution. Follow up with a clean, dry soft cloth.

Avoid exposing furniture to extreme heat or cold; also avoid wide humidity variance.

It is recommended to thoroughly rinse with clean water and wipe completely dry after exposure to cleaners/disinfectants.

	PAIN
ANTIMICROBIAL	No
CLEANING	Mild Soap & Water
BLEACH/WATER SOLUTION 1:10 (10%)	Yes
CLEAR AMMONIA ALL-PURPOSE CLEANER	Yes
CLOROX HEALTHCARE® DISPATCH® HOSPITAL CLEANER DISINFECTANT WITH BLEACH	Yes
DIVERSEY™ VIREX® II 256	Yes
ECOLAB® A-456® II	Yes
ECOLAB® ENDURE 320 HAND SANITIZER	Yes
ECOLAB® OXYCIDE™ DAILY DISINFECTANT CLEANER	Yes
ECOLAB® PEROXIDE MULTI SURFACE CLEANER AND DISINFECTANT	Yes
ETHANOL 95%	Yes
EVACLEAN™ PURTABS	Yes

## Paint (Continued)

	PAINT
FORMULA 409® ANTIBACTERIAL ALL-PURPOSE CLEANER	Yes
GCLEAN® G200 SURFACE SANITIZER	Yes
HILLYARD FOAMING HAND SANITIZER	Yes
HYDROGEN PEROXIDE (3% SOLUTION. THIS IS NOT HYDROGEN PEROXIDE VAPOR/MIST)	Yes
ISOPROPYL ALCOHOL 91%	Yes
JAY-KEM PH NEUTRAL COMMERCIAL FLOOR CLEANER	Yes
LYSOL® DISINFECTANT SPRAY	Yes
LYSOL® DISINFECTANT MAX COVER MIST	Yes
LYSOL® DISINFECTING WIPES	Yes
LYSOL® DISINFECTING WIPES	Yes
NIXALL® DISINFECTANT/SANITIZER	Yes
PINE SOL ALL PURPOSE CLEANER	Yes
PROKURE®	Yes
RECKIT BENCKIER/LYSOL ONE STEP FLOOR CLEANER	Yes

## Paint (Continued)

	PAIN
SIMPLE GREEN®	Yes
SSS® SANOTRACIN	Yes
VITAL OXIDE®	Yes
WEXFORD WEX-CIDE 128	Yes
WINDEX®	Yes

## Panel Fabrics

### Cleaning Codes Explained

- **W:** Use water-based cleaning solutions (Resolve™ Upholstery Cleaner, or mix 2 tbsp of ammonia or ammoniated detergent, such as Ajax® liquid, to 1 qt of water). Blot the stain gently with a cloth dampened in this solution. Continue turning the cloth to always use a clean portion.

It is recommended to thoroughly rinse with clean water and wipe completely dry after exposure to cleaners/disinfectants.

	GRADE A										GRADE B								
	Compose	Crossroads	Fusion	Infuse	Meander	Merge	Mykel	Plinth	Tapestry	Universe	Basket	Frenzied	Fuse	Linen	Lyko	Pact	Prose	Saville	Tenor
ANTIMICROBIAL	No	No	No	No	No	No	No	No	No	NO	No	No	No	No	No	No	No	No	No
CLEANING	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W

## Resin

	RESINS			
	Alpine White	Mist	Breeze	Glacier
ANTIMICROBIAL	No	No	No	No
CLEANING	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water
BLEACH/WATER SOLUTION 1:4	Yes	Yes	Yes	Yes

## Resin (Continued)

	RESINS			
	Alpine White	Mist	Breeze	Glacier
BLEACH/WATER SOLUTION 1:5	Yes	Yes	Yes	Yes
BLEACH/WATER SOLUTION 1:10 (10%)	Yes	Yes	Yes	Yes
BLEACH/WATER SOLUTION 1:100	Yes	Yes	Yes	Yes
BRILLIANIZE® PLASTIC CLEANER	Yes	Yes	Yes	Yes
CITRUS H2O2	No	No	No	No
CLOROX® BROAD SPECTRUM QUATERNARY DISINFECTANT CLEANER	No	No	No	No
CLOROX® PRO QUATERNARY ALL-PURPOSE CLEANER	No	No	No	No
CLOROX HEALTHCARE® DISPATCH® HOSPITAL CLEANER DISINFECTANT WITH BLEACH	Yes	Yes	Yes	Yes
CLOROX HEALTHCARE® BLEACH GERMICIDAL CLEANER	Yes	Yes	Yes	Yes
CLOROX HEALTHCARE® BLEACH GERMICIDAL WIPES	Yes	Yes	Yes	Yes
CLOROX HEALTHCARE® HYDROGEN PEROXIDE CLEANER DISINFECTANT WIPES	No	No	No	No
ECOLAB® QUATERNARY DISINFECTANT CLEANER	No	No	No	No
FANTASTIK® ALL PURPOSE CLEANER	No	No	No	No

## Resin (Continued)

	RESINS			
	Alpine White	Mist	Breeze	Glacier
FANTASTIK® ALL PURPOSE CLEANER - 1:1 SOLUTION	No	No	No	No
FORMULA 409® ANTIBACTERIAL ALL-PURPOSE CLEANER	No	No	No	No
FORMULA 409® ANTIBACTERIAL ALL-PURPOSE CLEANER: 1:1 SOLUTION	No	No	No	No
GLASS PLUS®	No	No	No	No
HYDROGEN PEROXIDE (3% SOLUTION. THIS IS NOT HYDROGEN PEROXIDE VAPOR/MIST)	yes	Yes	Yes	Yes
HYDROGEN PEROXIDE (3% SOLUTION)	Yes	Yes	Yes	Yes
ISOPROPYL ALCOHOL	No	No	No	No
ISOPROPYL ALCOHOL (50% SOLUTION)	No	No	No	No
ISOPROPYL ALCOHOL (30% SOLUTION)	Yes	Yes	Yes	Yes
ISOPROPYL ALCOHOL (70% SOLUTION)	No	No	No	No
NOVUS® PLASTIC CLEAN AND SHINE	Yes	Yes	Yes	Yes
PDI® SANI-CLOTH® AF3 GERMICIDAL DISPOSABLE WIPES	No	No	No	No
PDI® SANI CLOTH® BLEACH GERMICIDAL DISPOSABLE WIPES	No	No	No	No

## Resin (Continued)

	RESINS			
	Alpine White	Mist	Breeze	Glacier
PDI® SANI-CLOTH® HB GERMICIDAL	No	No	No	No
PURELL ADVANCED INSTANT HAND SANITIZER	No	No	No	No
SCICAN OPTIM® 33TB	Yes	Yes	Yes	Yes
SCICAN OPTIM® 33TB WIPES	Yes	Yes	Yes	Yes
WINDEX®	No	No	No	No

	RESINS	
	Frosted Resin	Polycarbonate
ANTIMICROBIAL	No	No
CLEANING	Mild Soap & Water	Mild Soap & Water
BLEACH/WATER SOLUTION 1:10 (10%)	No	No
BLEACH/WATER SOLUTION 1:100	Yes	Yes
BRILLIANIZE® PLASTIC CLEANER	Yes	

## Resin (Continued)

	RESINS	
	Frosted Resin	Polycarbonate
CLOROX HEALTHCARE® DISPATCH® HOSPITAL CLEANER DISINFECTANT WITH BLEACH		Yes
CLOROX HEALTHCARE® BLEACH GERMICIDAL WIPES	Yes	
DIVERSEY™ VIREX® II 256		Yes
ECOLAB® A-456® II		Yes
ECOLAB® ENDURE 320 HAND SANITIZER		Yes
ECOLAB® OXYCIDE™ DAILY DISINFECTANT CLEANER		Yes
ETHANOL 95%		Yes
HILLYARD HS		Yes
HYDROGEN PEROXIDE		
HYDROGEN PEROXIDE (3% SOLUTION)	Yes	Yes
ISOPROPYL ALCOHOL		
ISOPROPYL ALCOHOL (91%)	No	Yes
ISOPROPYL ALCOHOL (30% SOLUTION)	Yes	
JAY-KEM PH NEUTRAL COMMERCIAL FLOOR CLEANER		Yes



## Resin (Continued)

	RESINS	
	Frosted Resin	Polycarbonate
LYSOL DISINFECTANT SPRAY		Yes
LYSOL DISINFECTANT MAX COVER MIST		Yes
LYSOL DISINFECTING WIPES		Yes
LYSOL ONE STEP FLOOR CLEANER		Yes
NOVUS® PLASTIC CLEAN AND SHINE	Yes	
PINE SOL ALL PURPOSE CLEANER		Yes
SIMPLE GREEN®		Yes
SSS® SANOTRACIN		Yes
WEXFORD WEX-CIDE 128		Yes
WINDEX®		Yes

## Seating

### Cleaning Codes Explained

- **W:** Use water-based cleaning solutions (Resolve™ Upholstery Cleaner, or mix 2 tbsp of ammonia or ammoniated detergent, such as Ajax® liquid, to 1 qt of water). Blot the stain gently with a cloth dampened in this solution. Continue turning the cloth to always use a clean portion.
- **WS:** Use mild, pure, water-free dry cleaning solvents (Energine® or Carbona®). Wet a cloth with the spot cleaner and follow the procedure described above. Cleaning by a professional furniture service is recommended.

### Common Spills And Suggested Clean Up

Always brush fabric before cleaning to remove excess dirt and dust. A small area should be tested prior to general cleaning.

- **Blood (W):** Treat with cold water and table salt mixture (2 tbsp salt to 1 qt of water). Rinse and blot with a towel. If stain persists, use diluted ammonia.
- **Candle Wax (WS):** Gently scrape away surface wax with spatula or dull knife. Cover the wax with several layers of paper towel and apply a warm iron.
- **Chewing Gum (WS):** Freeze with ice. Remove with spatula or dull knife.
- **Chocolate or Coffee:** Freeze with ice. Sponge with lukewarm water.
- **Fruit Juice or Berry Stains:** Treat with cold water.
- **Grease, Cooking Oil, Bacon Fat etc. (WS)**
- **Ink or Markers (W):** Use rubbing alcohol.
- **Mud (W):** Lift away pieces that can be removed with a spatula or dull knife. Let dry, then vacuum. If stain persists, clean with a cloth dampened with ammonia-water solution.
- **Pencil Lead or Rubber Cement (S)**
- **Perspiration, Mucilage, Urine (W)**
- **Vomit:** Treat with cold water and unseasoned meat tenderizer. Let sit for 10-15 minutes. Rinse, let dry, then vacuum.

It is recommended to thoroughly rinse with clean water and wipe completely dry after exposure to cleaners/disinfectants.

For specific cleaning information on your selected material, please click on the hyperlink in the matrix for additional information.

## Seating Upholstery: Mesh

	JOYA	ITSA	WISH
ANTIMICROBIAL	No	No	
CLEANING	W	W	
BLEACH/WATER SOLUTION 1:4	No		
BLEACH/WATER SOLUTION 1:5	No		
BLEACH/WATER SOLUTION 1:10 (10%)	No	Yes	
CALTECH® DISPATCH® (1:10 DILUTION)	No		
CITRUS H2O2	Yes		
CLOROX® CLEAN-UP® WITH BLEACH	No		
CLOROX HEALTHCARE® DISPATCH® HOSPITAL CLEANER DISINFECTANT WITH BLEACH	No		
CLOROXHEALTHCARE® DISPATCH® HOSPITAL CLEANER DISINFECTANT TOWELS WITH BLEACH	No		
CLOROXPRO™ GERMICIDAL BLEACH	No		
CLOROX HEALTHCARE® BLEACH GERMICIDAL CLEANER	No		
CLOROX HEALTHCARE® BLEACH GERMICIDAL WIPES	No		
CONTEC® PERIDOXRTU®	Yes		

## Seating Upholstery: Mesh (Continued)

	JOYA	ITSA	WISH
CURRENT TECHNOLOGIES BLEACH-RITE® DISINFECTING SPRAY	No		
DIVERSEY™ OXIVIR® 1	Yes		
DIVERSEY™ OXIVIR® 1 RTU	Yes		
DIVERSEY™ OXIVIR® FIVE 16			
DIVERSEY™ OXIVIR® TB	Yes		
DIVERSEY™ OXIVIR® TB WIPES	Yes		
DIVERSEY™ VIREX® II 256		Yes	
ECOLAB® A-456® II		Yes	
ECOLAB® ENDURE 320 HAND SANITIZER			
ECOLAB® VIRASEPT™	Yes	Yes	
ETHANOL 55-70%		Yes	
FORMULA 409® ANTIBACTERIAL ALL-PURPOSE CLEANER		Yes	
HYDROGEN PEROXIDE (3% SOLUTION. THIS IS NOT HYDROGEN PEROXIDE VAPOR/MIST)	Yes	Yes	
ISOPROPYL/RUBBING ALCOHOL (70%)		Yes	

## Seating Upholstery: Mesh (Continued)

	JOYA	ITSA	WISH
LYSOL DISINFECTANT MAX COVER MIST			Yes
LYSOL DISINFECTANT WIPES			Yes
RECKIT BENCKIER/LYSOL ONE STEP FLOOR CLEANER		Yes	Yes
PDI® SANI CLOTH® BLEACH GERMICIDAL DISPOSABLE WIPES	No		
SIMPLE GREEN®		Yes	
SSS® PERISEPT	Yes		
SSS® SANOTRACIN	Yes	Yes	
STERIS COVERAGE® SPRAY HB	Yes		
VIROX® ACCEL® TB WIPES	Yes		
WEXFORD WEX-CIDE 128		Yes	
WINDEX® ORIGINAL FORMULA/ S.C. JOHNSON		Yes	

## Seating Upholstery: Non-Woven

	GRADE 2	GRADE 3	GRADE 4		GRADE 5	GRADE 6	L7	L8	
	<a href="#">Sedona</a>	Dolce	<a href="#">Masquerade</a>	<a href="#">Silververtex</a>	Chambray	<a href="#">Essence</a>	<a href="#">Davenport</a>	<a href="#">Florence</a>	<a href="#">Showcase</a>
ANTIMICROBIAL	No	No	No	Yes	No	No	No	Yes	No
CLEANING	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water
303 FABRIC/VINYL CLEANER (DILUTION: 4 OZ IN 1 GALLON WATER)	Yes	Yes	Yes	Yes	Yes				
3M™ NEUTRAL CLEANER 3L						Yes			
3M™ NEUTRAL QUAT 23L						Yes			
BIOTROL™ BIREX® QUAT™						Yes			
BLEACH/WATER SOLUTION 1:5						Yes	Yes	Yes	
BLEACH/WATER SOLUTION 1:10 (10%)	Yes	Yes	Yes	Yes	Yes			Yes	
CALTECHX® DISPATCH® (1:10 DILUTION)	Yes	Yes	Yes	Yes	Yes				
CLICKSAN® DISINFECTANT								Yes	
CLOROX® CLEAN-UP® WITH BLEACH								Yes	
CLOROX® DISINFECTING WIPES						Yes		Yes	

## Seating Upholstery: Non-Woven (Continued)

	GRADE 2	GRADE 3	GRADE 4		GRADE 5	GRADE 6	L7	L8	
	<a href="#">Sedona</a>	Dolce	<a href="#">Masquerade</a>	<a href="#">Silververtex</a>	Chambray	<a href="#">Essence</a>	<a href="#">Davenport</a>	<a href="#">Florence</a>	<a href="#">Showcase</a>
CLOROX HEALTHCARE® DISPATCH® HOSPITAL CLEANER DISINFECTANT WITH BLEACH						Yes			
CLOROXPRO™ GERMICIDAL BLEACH						Yes			
CLOROX HEALTHCARE® BLEACH GERMICIDAL WIPES	Yes	Yes	Yes	Yes	Yes				
CLOROX HEALTHCARE® HYDROGEN PEROXIDE CLEANER DISINFECTANT WIPES	Yes	Yes	Yes	Yes	Yes				
CORTINA LEATHERS UNIVERSAL CLEANER HIGH-TECH WIPES								Yes	
DIVERSEY™ GLANCE® NA DILUTED (1:50 WATER)	Yes	Yes	Yes	Yes	Yes				
DIVERSEY™ GP FORWARD DILUTED (1:64 WATER)	Yes	Yes	Yes	Yes	Yes				
DIVERSEY™ OXIVIR® TB WIPES	Yes	Yes	Yes	Yes	Yes				
DIVERSEY™ STRIDE® FLORAL NEUTRAL (1:32 WATER) - DAILY CLEANING (1:64 WATER- CLEANING EXCESS DIRT)	Yes	Yes	Yes	Yes	Yes				
DIVERSEY™ STRIDE® FRAGRANCE FREE NEUTRAL CLEANER	Yes	Yes	Yes	Yes	Yes				
DIVERSEY™ VIREX® II 256	Yes	Yes	Yes	Yes	Yes	Yes			
DIVERSEY™ VIREX® TB						Yes			

## Seating Upholstery: Non-Woven (Continued)

	GRADE 2	GRADE 3	GRADE 4		GRADE 5	GRADE 6	L7	L8	
	<a href="#">Sedona</a>	Dolce	<a href="#">Masquerade</a>	<a href="#">Silververtex</a>	Chambray	<a href="#">Essence</a>	<a href="#">Davenport</a>	<a href="#">Florence</a>	<a href="#">Showcase</a>
DIVERSEY™ VIROX™ AHP® 5 CONCENTRATE						Yes			
DIVERSEY™ VIROX™ AHP® 5 RTU	Yes	Yes	Yes	Yes	Yes				
ECOLAB® ASEPTICARE™ TB II	Yes	Yes	Yes	Yes	Yes	Yes			
ECOLAB® DISCIDE®						Yes			
ECOLAB® OXYCIDE™ DAILY DISINFECTANT CLEANER	Yes	Yes	Yes	Yes	Yes	Yes			
ESTEEM™ SANI-NC USE								Yes	
FANTASTIK® ALL PURPOSE CLEANER		Yes	Yes	Yes	Yes	Yes		Yes	
FANTASTIK® ALL PURPOSE CLEANER - 1:1 SOLUTION	Yes								
FORMULA 409® ANTIBACTERIAL ALL-PURPOSE CLEANER		Yes	Yes	Yes	Yes	Yes		Yes	
FORMULA 409® ANTIBACTERIAL ALL-PURPOSE CLEANER: 1:1 SOLUTION	Yes								
HYDROGEN PEROXIDE (3% SOLUTION. THIS IS NOT HYDROGEN PEROXIDE VAPOR/MIST)						Yes			
ISOPROPYL ALCOHOL 1:1 SOLUTION	No	Yes	Yes	Yes	Yes				
ISOPROPYL/RUBBING ALCOHOL (70%)						Yes			



## Seating Upholstery: Non-Woven (Continued)

	GRADE 2	GRADE 3	GRADE 4		GRADE 5	GRADE 6	L7	L8	
	<a href="#">Sedona</a>	Dolce	<a href="#">Masquerade</a>	<a href="#">Silvertext</a>	Chambray	<a href="#">Essence</a>	<a href="#">Davenport</a>	<a href="#">Florence</a>	<a href="#">Showcase</a>
KAY® INSTANT SOLUTIONS GLASS CLEANER								Yes	
KAY® QSR LIQUID CLEANER								Yes	
LYSOL® I.C. FOAMING DISINFECTANT CLEANER	Yes	Yes	Yes	Yes	Yes				
METREX™ CAVIWIPES						Yes			
METREX™ CAVIWIPES1™									
METREX™ CAVIWIPES XL™ PACKED	No	Yes	Yes	Yes	Yes				
PDI® SANI-CLOTH® AF3 GERMICIDAL DISPOSABLE WIPES	Yes	Yes	Yes	Yes	Yes				
PDI® SANI CLOTH® BLEACH GERMICIDAL DISPOSABLE WIPES						Yes			
PDI® SANI-CLOTH® PLUS GERMICIDAL DISPOSABLE WIPE						Yes			
PDI® SUPER SANI-CLOTH® GERMICIDAL DISPOSABLE WIPE	Yes	Yes	Yes	Yes	Yes	Yes			
SIMPLE GREEN® : DILUTION 1:30	Yes	Yes	Yes	Yes	Yes				
SIMPLE GREEN® TOWELS	Yes	Yes	Yes	Yes	Yes				
VERIDIEN VIRAGUARD®						Yes			

## Seating Upholstery: Non-Woven (Continued)

	GRADE 2	GRADE 3	GRADE 4		GRADE 5	GRADE 6	L7	L8	
	<a href="#">Sedona</a>	Dolce	<a href="#">Masquerade</a>	<a href="#">Silververtex</a>	Chambray	<a href="#">Essence</a>	<a href="#">Davenport</a>	<a href="#">Florence</a>	<a href="#">Showcase</a>
VIROX® ACCEL® TB WIPES						Yes			
WEXFORD WEX-CIDE 128	Yes	Yes	Yes	Yes	Yes				
WOOLITE®								Yes	

## Seating: Plastic

	LUSSO	PEP	POLY
ANTIMICROBIAL	No	No	No
CLEANING	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water
BLEACH/WATER SOLUTION 1:10 (10%)	Yes	Yes	Yes
CLEAR AMMONIA ALL-PURPOSE CLEANER	Yes	Yes	Yes
CLOROXHEALTHCARE® DISPATCH® HOSPITAL CLEANER DISINFECTANT TOWELS WITH BLEACH	Yes	Yes	Yes
DIVERSEY™ VIREX® II 256	Yes	Yes	Yes
ECOLAB® A-456® II	Yes	Yes	Yes

## Seating: Plastic

	LUSSO	PEP	POLY
Ecolab® Endure 320 Hand Sanitizer	Yes	Yes	Yes
Ecolab® Oxycide™ Daily Disinfectant Cleaner	Yes	Yes	Yes
Ethanol 95%	Yes	No	Yes
Hillyard Foaming Hand Sanitizer	Yes	Yes	Yes
Hydrogen Peroxide (3% Solution. This is not Hydrogen Peroxide Vapor/Mist)	Yes	Yes	Yes
Hydrogen Peroxide	Yes	Yes	Yes
Isopropyl Alcohol (91%)	Yes	No	Yes
Jay-Kem pH Neutral Commercial Floor Cleaner	Yes	Yes	Yes
Lysol® Disinfectant Spray	Yes	No	Yes
Lysol® Disinfectant Max Cover Mist	Yes	No	Yes
Lysol® Disinfecting Wipes	Yes	No	Yes
Reckit Benckier/Lysol One Step Floor Cleaner	Yes	Yes	Yes
Pine Sol All Purpose Cleaner	Yes	Yes	Yes
Simple Green®	Yes	Yes	Yes
SSS® Sanotracin	Yes	Yes	Yes
Wexford Wex-Cide 128	Yes	Yes	Yes

## Seating Upholstery: Woven

	GRADE 1											GRADE 2										GRADE 3			G4	G5		
	<u>Blink</u>	<u>Cali</u>	Disperse	Entwine	<u>Input</u>	Melange	<u>Moment</u>	<u>Soundbyte</u>	Spark	<u>Vessel</u>	Zig Zag	<u>Bliss</u>	Cadence	<u>Couture</u>	Dorset	Mingle	Parenthesis	<u>Phrase</u>	<u>Reason</u>	Spectrum	Stancil	<u>Twilight</u>	Bobby	Graph	Intuition	Slice	<u>Mode</u>	
ANTIMICROBIAL	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No
CLEANING	W	W	W	W	WS	W	W	W	W	W	W	W	WS	W	W	W	W	W	WS	W	W	W	WS	WS	WS	W	WS	WS
BLEACH/WATER SOLUTION 1:10 (10%)	No	No	No	No	Yes	No	No	No	No	No	No	No	No	No	No	No	No	Yes	No	No	No	No	No	No	No	No	No	No

## Solid Surface

	<a href="#">CORIAN GRADE A-D</a>	<a href="#">ANTIQUE WHITE</a>	<a href="#">DESIGNER WHITE</a>	<a href="#">FROSTY WHITE</a>	<a href="#">495 EOS BEIGE</a>	<a href="#">496 EOS GREY</a>
ANTIMICROBIAL	No	No	No	No	No	No
CLEANING	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water
	Commercial Solid Surface Cleaners: CLR® Lime-A-Way®	Commercial Solid Surface Cleaners: CLR® Lime-A-Way®	Commercial Solid Surface Cleaners: CLR® Lime-A-Way®	Commercial Solid Surface Cleaners: CLR® Lime-A-Way®	Commercial Solid Surface Cleaners: CLR® Lime-A-Way®	Commercial Solid Surface Cleaners: CLR® Lime-A-Way®
303 FABRIC/VINYL CLEANER (DILUTION: 4 OZ IN 1 GALLON WATER)					Yes	Yes
3M™ C. DIFF SOLUTION TABLETS					Yes	Yes
3M™ HB QUAT #25					Yes	Yes
3M™ NEUTRAL CLEANER 3H					Yes	Yes
3M™ NEUTRAL CLEANER 3L					Yes	Yes
3M™ NEUTRAL QUAT					Yes	Yes
3M™ NEUTRAL QUAT 23L					Yes	Yes
3M™ RCT CONCENTRATE 40L					Yes	Yes
3M™ TWIST-N-FILL #23					Yes	Yes
AGAR™ POWERQUAT					Yes	Yes
BENEFACT®					Yes	Yes

## Solid Surface (Continued)

	<a href="#">CORIAN GRADE A-D</a>	<a href="#">ANTIQUE WHITE</a>	<a href="#">DESIGNER WHITE</a>	<a href="#">FROSTY WHITE</a>	<a href="#">495 EOS BEIGE</a>	<a href="#">496 EOS GREY</a>
BETCO® QUAT-STAT™ 5					Yes	Yes
BIOTROL™ BIREX® QUAT™					Yes	Yes
BIORTROL™ BIREX SE®					Yes	Yes
BLEACH/WATER SOLUTION 1:4					Yes	Yes
BLEACH/WATER SOLUTION 1:10 (10%)		Yes	Yes	Yes	Yes	Yes
BLEACH/WATER SOLUTION 1:100	Yes	Yes	Yes	Yes	Yes	Yes
CALTECH® CITRACE®					Yes	Yes
CALTECH® DISPATCH® (1:10 DILUTION)					Yes	Yes
CALTECH® PRECISE® HOSPITAL FOAM CLEANER DISINFECTANT					Yes	Yes
CALTECH® PRECISE® QTB SPRAY					Yes	Yes
CITRUS H2O2					Yes	Yes
CLEAR AMMONIA ALL-PURPOSE CLEANER	Yes				Yes	Yes
CLOROX® BROAD SPECTRUM QUATERNARY DISINFECTANT CLEANER					Yes	Yes
CLOROX® CLEAN-UP® WITH BLEACH					Yes	Yes
CLOROX® DISINFECTING WIPES					Yes	Yes

## Solid Surface (Continued)

	<a href="#">CORIAN GRADE A-D</a>	<a href="#">ANTIQUE WHITE</a>	<a href="#">DESIGNER WHITE</a>	<a href="#">FROSTY WHITE</a>	<a href="#">495 EOS BEIGE</a>	<a href="#">496 EOS GREY</a>
CLOROX® PRO QUATERNARY ALL-PURPOSE CLEANER					Yes	Yes
CLOROX HEALTHCARE® DISPATCH® HOSPITAL CLEANER DISINFECTANT WITH BLEACH	Yes				Yes	Yes
CLOROX HEALTHCARE® DISPATCH® HOSPITAL CLEANER DISINFECTANT TOWELS WITH BLEACH					Yes	Yes
CLOROXPRO™ GERMICIDAL BLEACH					Yes	Yes
CLOROX HEALTHCARE® BLEACH GERMICIDAL CLEANER					Yes	Yes
CLOROX HEALTHCARE® BLEACH GERMICIDAL WIPES					Yes	Yes
CLOROX HEALTHCARE® EZ-KILL WIPES					Yes	Yes
CLOROX HEALTHCARE® HYDROGEN PEROXIDE CLEANER DISINFECTANT WIPES					Yes	Yes
CLOROX HEALTHCARE® VERSASURE™ ALCOHOL-FREE DISINFECTANT CLEANER WIPES					Yes	Yes
CONTEC® PERIDOXRTU®					Yes	Yes
CURRENT TECHNOLOGIES BLEACH-RITE® DISINFECTING SPRAY					Yes	Yes
DIVERSEY™ ACCEL® PREVENTION					Yes	Yes
DIVERSEY™ ACCEL® INTERVENTION WIPES					Yes	Yes

## Solid Surface (Continued)

	<a href="#">CORIAN GRADE A-D</a>	<a href="#">ANTIQUÉ WHITE</a>	<a href="#">DESIGNER WHITE</a>	<a href="#">FROSTY WHITE</a>	<a href="#">495 EOS BEIGE</a>	<a href="#">496 EOS GREY</a>
DIVERSEY™ AVERT™ DISINFECTANT CLEANER					Yes	Yes
DIVERSEY™ EXPOSE® II 256					Yes	Yes
DIVERSEY™ GLANCE® NA DILUTED (1:50 WATER)					Yes	Yes
DIVERSEY™ GP FORWARD DILUTED (1:64 WATER)					Yes	Yes
DIVERSEY™ MORNING MIST® NEUTRAL DISINFECTANT CLEANER					Yes	Yes
DIVERSEY™ OXIVIR® 1					Yes	Yes
DIVERSEY™ OXIVIR® 1 RTU					Yes	Yes
DIVERSEY™ OXIVIR® FIVE 16					Yes	Yes
DIVERSEY™ OXIVIR® TB					Yes	Yes
DIVERSEY™ OXIVIR® TB WIPES					Yes	Yes
DIVERSEY™ STRIDE® FLORAL NEUTRAL CLEANER					Yes	Yes
DIVERSEY™ STRIDE® FRAGRANCE FREE NEUTRAL CLEANER					Yes	Yes
DIVERSEY™ TRIAD® III					Yes	Yes
DIVERSEY™ VIREX® II 256	Yes	Yes	Yes	Yes	Yes	Yes
DIVERSEY™ VIREX® TB					Yes	Yes



## Solid Surface (Continued)

	<a href="#">CORIAN GRADE A-D</a>	<a href="#">ANTIQUE WHITE</a>	<a href="#">DESIGNER WHITE</a>	<a href="#">FROSTY WHITE</a>	<a href="#">495 EOS BEIGE</a>	<a href="#">496 EOS GREY</a>
DIVERSEY™ VIREX® PLUS					Yes	Yes
DIVERSEY™ VIROX™ AHP® 5 CONCENTRATE					Yes	Yes
DIVERSEY™ VIROX™ AHP® 5 RTU					Yes	Yes
ECOLAB® A-456® II	Yes				Yes	Yes
ECOLAB® ASEPTICARE™					Yes	Yes
ECOLAB® ASEPTICARE™ TB II					Yes	Yes
ECOLAB® DISCIDE®					Yes	Yes
ECOLAB® ENDURE 320 HAND SANITIZER	Yes				Yes	Yes
ECOLAB® NEUTRAL DISINFECTANT CLEANER					Yes	Yes
ECOLAB® OASIS® 146					Yes	Yes
ECOLAB® OXYCIDE™ DAILY DISINFECTANT CLEANER					Yes	Yes
ECOLAB® QUATERNARY DISINFECTANT CLEANER					Yes	Yes
ECOLAB® VIRASEPT™					Yes	Yes
ERC PERFORMANCE WIPES					Yes	Yes
ETHANOL	Yes				Yes	Yes

## Solid Surface (Continued)

	<a href="#">CORIAN GRADE A-D</a>	<a href="#">ANTIQUE WHITE</a>	<a href="#">DESIGNER WHITE</a>	<a href="#">FROSTY WHITE</a>	<a href="#">495 EOS BEIGE</a>	<a href="#">496 EOS GREY</a>
FANTASTIK® ALL PURPOSE CLEANER					Yes	Yes
FIBERLOCK SHOCKWAVE					Yes	Yes
FORMULA 409® ANTIBACTERIAL ALL-PURPOSE CLEANER					Yes	Yes
GLASS PLUS®	No				Yes	Yes
GREASED LIGHTNING® MULTI PURPOSE					Yes	Yes
HYDROGEN PEROXIDE (3% SOLUTION. THIS IS NOT HYDROGEN PEROXIDE VAPOR/MIST)	Yes				Yes	Yes
HYDROGEN PEROXIDE	Yes				Yes	Yes
ISOPROPYL ALCOHOL					Yes	Yes
ISOPROPYL/RUBBING ALCOHOL (70%)		Yes			Yes	Yes
JAY-KEM PH NEUTRAL COMMERCIAL FLOOR CLEANER	Yes				Yes	Yes
LYSOL®					Yes	Yes
LYSOL® ADVANCED CLEANING DISINFECTING WIPES					Yes	Yes
LYSOL® DISINFECTANT SPRAY	Yes	Yes	Yes	Yes	Yes	Yes
LYSOL® DISINFECTANT MAX COVER MIST	Yes	Yes	Yes	Yes	Yes	Yes

## Solid Surface (Continued)

	<a href="#">CORIAN GRADE A-D</a>	<a href="#">ANTIQUE WHITE</a>	<a href="#">DESIGNER WHITE</a>	<a href="#">FROSTY WHITE</a>	<a href="#">495 EOS BEIGE</a>	<a href="#">496 EOS GREY</a>
LYSOL® DISINFECTING WIPES	Yes	Yes	Yes	Yes	Yes	Yes
LYSOL® I.C. FOAMING DISINFECTANT CLEANER					Yes	Yes
LYSOL ONE STEP FLOOR CLEANER	Yes				Yes	Yes
LYSOL® WIPES					Yes	Yes
LYSOL® DISINFECTING WIPES					Yes	Yes
MAINTEX™ OXY CITRUS					Yes	Yes
MCKESSON DISPOSABLE GERMICIDAL SURFACE WIPES					Yes	Yes
MCKESSON PRO-TECH RTU DISINFECTANT CLEANER					Yes	Yes
METREX™ CAVICIDE™					Yes	Yes
METREX™ CAVICIDE1™					Yes	Yes
METREX™ CAVICIDE™ AF					Yes	Yes
METREX™ CAVIWIPES					Yes	Yes
METREX™ CAVIWIPES1™					Yes	Yes
METREX™ CAVIWIPES XL™ PACKED					Yes	Yes
MICROBAN					Yes	Yes

## Solid Surface (Continued)

	CORIAN GRADE A-D	ANTIQUE WHITE	DESIGNER WHITE	FROSTY WHITE	495 EOS BEIGE	496 EOS GREY
MR. CLEAN®					Yes	Yes
NCL® AVISTAT-D™ READY TO USE SPRAY DISINFECTANT CLEANER					Yes	Yes
NCL® MICRO-CHEM PLUS™					Yes	Yes
NOVUS® PLASTIC CLEAN AND SHINE					Yes	Yes
PALMOLIVE LIQUID					Yes	Yes
PALMERO DISCIDE® WIPES					Yes	Yes
PCS SODIUM HYPOCHLORITE DISINFECTANT/DISINFECTANT CLEANER - DILUTION: 0.5 OZ / QUART WATER					Yes	Yes
PDI® SANI-CLOTH® AF3 GERMICIDAL DISPOSABLE WIPES					Yes	Yes
PDI® SANI CLOTH® BLEACH GERMICIDAL DISPOSABLE WIPES					Yes	Yes
PDI® SANI-CLOTH® HB GERMICIDAL					Yes	Yes
PDI® SANI-CLOTH® PLUS GERMICIDAL DISPOSABLE WIPE					Yes	Yes
PDI® SANI-CLOTH® PRIME GERMICIDAL DISPOSABLE WIPE					Yes	Yes
PDI® SANI-HANDS® INSTANT HAND SANITIZING WIPE					Yes	Yes
PDI® SANI-PRIME® GERMICIDAL SPRAY					Yes	Yes

## Solid Surface (Continued)

	<a href="#">CORIAN GRADE A-D</a>	<a href="#">ANTIQUE WHITE</a>	<a href="#">DESIGNER WHITE</a>	<a href="#">FROSTY WHITE</a>	<a href="#">495 EOS BEIGE</a>	<a href="#">496 EOS GREY</a>
PDI® SUPER SANI-CLOTH® GERMICIDAL DISPOSABLE WIPE					Yes	Yes
PINE SOL ALL PURPOSE CLEANER	Yes				Yes	Yes
PURELL ADVANCED INSTANT HAND SANITIZER					Yes	Yes
RUSS MEDICAL FADE-A-DYNE II					Yes	Yes
SAFETEC® SANIZIDE®					Yes	Yes
SAFETEC® SANIZIDE PLUS®					Yes	Yes
SANI-KLEEN BROAD-CIDE 128					Yes	Yes
SCICAN OPTIM® 1 WIPES					Yes	Yes
SCICAN OPTIM® 33TB					Yes	Yes
SCICAN OPTIM® 33TB WIPES					Yes	Yes
SIMPLE GREEN®	Yes	Yes			Yes	Yes
SIMPLE GREEN® TOWELS					Yes	Yes
SSS® PERISEPT					Yes	Yes
SSS® SANOTRACIN	Yes	Yes			Yes	Yes
STERIS COVERAGE® SPRAY HB					Yes	Yes

## Solid Surface (Continued)

	<a href="#">CORIAN GRADE A-D</a>	<a href="#">ANTIQUE WHITE</a>	<a href="#">DESIGNER WHITE</a>	<a href="#">FROSTY WHITE</a>	<a href="#">495 EOS BEIGE</a>	<a href="#">496 EOS GREY</a>
STERIS COVERAGE® PLUS GERMICIDAL WIPES					Yes	Yes
TEXAS GULF INDUSTRIES SANTIMINE 150					Yes	Yes
UNIMED ACCEL® TB					Yes	Yes
VERIDIEN VIRAGUARD®					Yes	Yes
VIROX® ACCEL® TB WIPES					Yes	Yes
VIROX® PREEMPT™ RTU					Yes	Yes
VIROX® RESCUE™					Yes	Yes
WEXFORD WEX-CIDE 128	Yes				Yes	Yes
WINDEX® ORIGINAL FORMULA	No				Yes	Yes

## Thermally Fused Laminates (TFL)

Wipe the surface, moving with the grain on laminate surfaces. Avoid exposing furniture to extreme heat or cold; also avoid wide humidity variance.

It is recommended to thoroughly rinse with clean water and wipe completely dry after exposure to cleaners/disinfectants

\* Causes slight change of gloss or color.

	THERMALLY FUSED LAMINATE (TFL)
ANTIMICROBIAL	*Yes
BLEACH/WATER SOLUTION 1:10 (10%)	Yes
CLEANING	Mild Soap & Water
AGAR™ POWERQUAT	Yes
BIORTROL™ BIREX SE®	Yes
BLEACH/WATER SOLUTION 1:5	Yes
CALTECH® CITRACE®	Yes
CALTECH® PRECISE® HOSPITAL FOAM CLEANER DISINFECTANT	Yes
CALTECH® PRECISE® QTB SPRAY	Yes
CLOROX® BROAD SPECTRUM QUATERNARY DISINFECTANT CLEANER	Yes
CLOROX HEALTHCARE® DISPATCH® HOSPITAL CLEANER DISINFECTANT WITH BLEACH	Yes
CLOROX HEALTHCARE® BLEACH GERMICIDAL CLEANER	Yes

## Thermally Fused Laminates (TFL) (Continued)

	THERMALLY FUSED LAMINATE (TFL)
CLOROX HEALTHCARE® BLEACH GERMICIDAL WIPES	Yes
CLOROX HEALTHCARE® EZ-KILL WIPES	Yes
CLOROX HEALTHCARE® VERSASURE™ ALCOHOL-FREE DISINFECTANT CLEANER WIPES	Yes
CURRENT TECHNOLOGIES BLEACH-RITE® DISINFECTING SPRAY	Yes
DIVERSEY™ ACCEL® INTERVENTION WIPES	Yes
DIVERSEY™ OXIVIR® 1 RTU	Yes
DIVERSEY™ OXIVIR® TB	Yes
DIVERSEY™ VIREX® II 256	Yes
DIVERSEY™ VIROX™ AHP® 5	Yes
ECOLAB® ASEPTICARE™	Yes
ECOLAB® ASEPTICARE™ TB II	Yes
ECOLAB® OXYCIDE™ DAILY DISINFECTANT CLEANER	Yes
ERC PERFORMANCE WIPES	Yes
FANTASTIK® ALL PURPOSE CLEANER	Yes
FORMULA 409® ANTIBACTERIAL ALL-PURPOSE CLEANER	Yes



## Thermally Fused Laminates (TFL) (Continued)

	THERMALLY FUSED LAMINATE (TFL)
LYSOL® DISINFECTANT SPRAY	Yes
LYSOL DISINFECTANT MAX COVER MIST	Yes
LYSOL ONE STEP FLOOR CLEANER	Yes
MCKESSON DISPOSABLE GERMICIDAL SURFACE WIPES	Yes
MCKESSON PRO-TECH RTU DISINFECTANT CLEANER	Yes
METREX™ CAVICIDE™	Yes
METREX™ CAVICIDE™ AF	Yes
NCL® AVISTAT-D™ READY TO USE SPRAY DISINFECTANT CLEANER	Yes
NCL® MICRO-CHEM PLUS™	Yes
PDI® SANI-CLOTH® AF3 GERMICIDAL DISPOSABLE WIPES	Yes
PDI® SANI-CLOTH® HB GERMICIDAL	Yes
PDI® SANI-CLOTH® PLUS GERMICIDAL DISPOSABLE WIPE	Yes
PDI® SUPER SANI-CLOTH® GERMICIDAL DISPOSABLE WIPE	Yes
RUSS MEDICAL FADE-A-DYNE II	Yes

## Thermally Fused Laminates (TFL) (Continued)

	THERMALLY FUSED LAMINATE (TFL)
SAFETEC® SANIZIDE PLUS®	Yes
SANI-KLEEN BROAD-CIDE 128	Yes
SCICAN OPTIM® 1 WIPES	Yes
SCICAN OPTIM® 33TB	Yes
TEXAS GULF INDUSTRIES SANTIMINE 150	Yes
VIROX® PREEMPT™ RTU	Yes
WEXFORD WEX-CIDE 128	Yes

## Wood

Ensure the lasting beauty and performance of your wood furniture with proper use and care.

- Clean surfaces with a water dampened soft cloth; always wipe with the grain and dry the surface completely.
- If needed, clean with a small amount of non-alkaline dish soap in warm water.
- Immediately remove any liquids from the furniture surface with a blotting action.
- Lift objects to remove them; never pull them across the surface.
- For an additional safeguard, use a protective desk pad. The single item could ensure a lasting finish by protecting your furniture from possible damage caused by pens or sharp objects.
- If using a protective glass top, place spacer pads under the glass to allow the wood to breathe.
- Avoid exposing furniture to extreme heat or cold; also avoid wide humidity variance.
- Avoid exposure of furniture to strong sunlight. Prolonged exposure may change the color of wood beneath the finish.
- Wood finishes can withstand cleaning solutions that include bleach (10%), hydrogen peroxide (Virox), alcohol (CaviWipes, hand sanitizers), quaternary ammonium compounds (Virex, Ecolab A-456 II, Lysol) and phenols (Wex-cide) when they are used in accordance with the disinfectants label instructions.

	SEATING WOOD FINISH	SEATING WOOD PAINT	KIMBALL BINGO	CONFERENCE TABLES, DESK, RETURN AND CREDENZA WORKSURFACES	VERTICAL PANELS, BOOKCASES, SHELVES, OCCASIONAL TABLES, LAMINATE WORKSURFACES WITH WOOD RIM.	TRADITIONAL HIGH END PRODUCT.
ANTIMICROBIAL	No	No	No	No	No	No
CLEANING	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water	Mild Soap & Water
BLEACH/WATER SOLUTION 1:10 (10%)	Yes	Yes	Yes	Yes	Yes	Yes

## Wood (Continued)

	SEATING WOOD FINISH	SEATING WOOD PAINT	KIMBALL BINGO	CONFERENCE TABLES, DESK, RETURN AND CREDENZA WORKSURFACES	VERTICAL PANELS, BOOKCASES, SHELVES, OCCASIONAL TABLES, LAMINATE WORKSURFACES WITH WOOD RIM.	TRADITIONAL HIGH END PRODUCT.
CLEAR AMMONIA ALL-PURPOSE CLEANER	Yes	Yes	Yes	Yes	Yes	Yes
CLOROX HEALTHCARE® DISPATCH® HOSPITAL CLEANER DISINFECTANT WITH BLEACH	Yes	Yes	Yes	Yes	Yes	Yes
DIVERSEY™ VIREX® II 256	Yes	Yes	Yes	Yes	Yes	Yes
ECOLAB® A-456® II	Yes	Yes	Yes	Yes	Yes	Yes
ECOLAB® ENDURE 320 HAND SANITIZER	Yes	Yes	Yes	Yes	Yes	Yes
ECOLAB® OXYCIDE™ DAILY DISINFECTANT CLEANER	Yes	Yes	Yes	Yes	Yes	Yes
ETHANOL 95%	Yes	Yes	Yes	Yes	Yes	Yes
HILLYARD FOAMING HAND SANITIZER	Yes	Yes	Yes	Yes	Yes	Yes
ISOPROPYL ALCOHOL (91%)	Yes	Yes	Yes	Yes	Yes	Yes
JAY-KEM PH NEUTRAL COMMERCIAL FLOOR CLEANER	Yes	Yes	Yes	Yes	Yes	Yes
LYSOL® DISINFECTANT SPRAY	Yes			Yes		
LYSOL® DISINFECTANT MAX COVER MIST	Yes			Yes		
LYSOL® DISINFECTING WIPES	Yes			Yes		

## Wood (Continued)

	SEATING WOOD FINISH	SEATING WOOD PAINT	KIMBALL BINGO	CONFERENCE TABLES, DESK, RETURN AND CREDENZA WORKSURFACES	VERTICAL PANELS, BOOKCASES, SHELVES, OCCASIONAL TABLES, LAMINATE WORKSURFACES WITH WOOD RIM.	TRADITIONAL HIGH END PRODUCT.
RECKIT BENCKIER/LYSOL ONE STEP FLOOR CLEANER	Yes	Yes	Yes	Yes	Yes	Yes
PINE SOL ALL PURPOSE CLEANER	Yes	Yes	Yes	Yes	Yes	Yes
SIMPLE GREEN®	Yes	Yes	Yes	Yes	Yes	Yes
SSS® SANOTRACIN	No	Yes	Yes	Yes	No	No
WEXFORD WEX-CIDE 128	Yes	Yes	Yes	Yes	Yes	Yes

## Wool Felt

	FELT
ANTIMICROBIAL	No
CLEANING	Vacuum clean regularly. Don't wash. Treat spillages immediately. Professional dryclean or wipe clean with a pH neutral soap and a damp cloth.